

Effect of Vibrotactile Stimulation on the Response Time to Handle Perturbation

Pilwon Hur, PhD (hur@uwm.edu), Yao-Hung Wan, Na Jin Seo, PhD

Hand Rehabilitation Lab, Department of Industrial Engineering, University of Wisconsin-Milwaukee, Milwaukee, WI



MOTIVATION

- Every year, more than 20,000 American workers get injured by falls from ladders [1].
- The direct compensation and medical costs associated with these falls are \$5.3 billion/year [2].
- Cutaneous sensation at the hand (increased pressure on the hand) was the earliest cue available for people to detect handle perturbation during simulated ladder fall (as opposed to proprioception) [3].
- Cutaneous sensation can be improved by applying vibrotactile stimulation (Fig 1) [4].

OBJECTIVE

- To determine if vibrotactile stimulation can shorten a person's response time to handle perturbation




Fig 1. Weak signal may not be detectable (left). If subthreshold random noise is added to the signal, the noise-added signal may be detectable (right), increasing tactile acuity.

METHODS

Subjects:

- 19 right-handed healthy young adults
- 15 males and 4 females, age = 25 ± 6 years
- The nondominant hand was tested since people usually use the dominant hand to perform works while holding rung with the nondominant hand.

Procedure:

- To simulate a ladder fall, a sudden upward load was applied at a random time to a handle that subject was lightly grasping (Fig 2).
- Subjects were instructed to stop the handle from moving up when they detected the perturbation.




Fig 2. Experimental setup. The handle moved up at a random time. The subjects were instructed to stop the handle as soon as they noticed perturbation.

Vibrotactile Device:

- The device (Fig 3) applied subthreshold random noise (<500 Hz) vibrotactile stimulation at 50% of the sensory threshold.




Fig 3 Vibrotactile device (C-3 Tactor, Engineering Acoustics, Inc., Casselberry, FL).

Test Conditions:

- Location: The device was attached at 4 different skin locations.
- Stimulation: ON vs. OFF
- All location and stimulation conditions were repeated 3 times in a random order.



RESULTS

The *reaction time* significantly reduced with stimulation ($p=0.026$, 99 ± 3 ms vs. 95 ± 3 ms, pooled for 4 sites). The location and interaction between stimulation and location did not significantly affect the reaction time ($p>.05$). The pairwise comparison showed that the *reaction time* significantly decreased with the fingertip stimulation ($p=0.018$, 99 ± 3 ms vs. 91 ± 3 ms).





Fig 4 The *reaction time* to handle perturbation. Vibrotactile stimulation enhanced the reaction time regardless of the stimulation location.

Measure:

- Response times of the following 8 muscles using surface EMG [5]



Data Analysis:

- Among 8 muscles' response times, the fastest response time determined the *reaction time*.
- Repeated measures ANOVA was used to determine the effects of stimulation and location on the *reaction time*.

CONCLUSION

- The application of vibrotactile stimulation enhanced persons' reaction time to handle perturbation.
- Enhanced reaction time using vibrotactile stimulation may help reduce falls from ladders.

ACKNOWLEDGEMENT

This work was supported by NIOSH UIC ERC T42 OH008672

REFERENCES

1. Christensen, T., Cooper, N., 67(11), 39-41., 2005
2. LibertyMutual, Workplace Safety Index. Liberty Mutual Research Institute for Safety, 2010
3. Motawar, B., et al., ASB 2010
4. Collins, J., et al., J Neurophysiol, 76(1), 642-645, 1996
5. Richardson, M., Muslce atlas of the extremities. Seattle. Bare bones books, 1997